

Printer

ACTIVE WEAR

MEASUREMENT LIST

Brand: PRINTER ACTIVE WEAR

Style: 2263015 POINT shirt



	XS	S	M	L	XL	XXL	3XL	4XL	5XL
body lenght CB		76,5	79	81,5	83,5	86	88	90,5	92,5
1/2 chest		52	55	58	62	66	70	74	78
Sleevelenght		65	67	69	70,5	72	73,5	75	76,5

All measurements are indicative with minimum tolerance of 1 cm